

WBEM event subscriptions for HP-UX systems managed by HP SIM 5.x



Introduction	2
System requirements	2
Required software on the managed systems	2
WBEM services	2
Event Monitoring Service, Online Diagnostics, and System Fault Management	2
Adding systems with WBEM to HP SIM through the command line interface	3
Adding systems with WBEM to HP SIM through the GUI	5
Sending a test indication	6
Viewing the WBEM indications	6
For more information	7

Introduction

Troubles that occur on hardware computing systems are called errors. These errors are cached in either nonvolatile memory, written to a file, or cached in memory. Various mechanisms have been created to notify network administrators of the existence of these errors. The most common mechanism is to have the error available to the SNMP application, which reads the cached data and forwards the error to a predefined list of IP or system addresses as an SNMP trap. System information that is not an error but an indication of system operation can be reported in the same manner.

WBEM is beginning to be the preferred method for reporting system errors and condition. This information is available for use through WBEM and is called error indications, or abbreviated as indications. Similar to SNMP, the WBEM application can forward these indications to a listing of addresses, also called subscribers. Common subscribers are system management applications such as HP Systems Insight Manager (HP SIM). A management application must make a proactive request to be a WBEM subscriber. All WBEM communications and subscription requests use the SSL protocol for security.

EMS on HP-UX can be configured to forward SNMP traps to HP SIM. With the appropriate software on the HP-UX system, EMS can be channeled (wrapped) to WBEM and be announced as indications to the WBEM subscribers.

This paper describes the software requirements for the HP-UX system, how to configure EMS for wrapping the SNMP traps to WBEM, and how to configure HP SIM to subscribe to HP-UX systems to receive the WBEM indications.

System requirements

WBEM indications can be configured on the following system types and operating system levels:

- System types
 - PA-RISC
 - Integrity Servers
- HP-UX Operating Systems
 - 11.0 – not available
 - 11/v1 – not available
 - 11/v2 update 2 (PA and Integrity)
- Linux operating systems
WBEM indications are not presently supported on Linux

Required software on the managed systems

The following software is required on the managed HP-UX system:

- OnlineDiag
- WBEM services for HP-UX 2.0.5 or above and appropriate patches
- System Fault Management (SysFaultMgmt)

The following are the specific information for each of the above.

WBEM services

The minimum requirement is WBEM services 2.0. Various versions are available depending upon your version of the operating system.

For HP-UX 11.23, WBEM Services A.2.0.5 or later is to be installed, along with the WBEM providers (also available on the OE for 11i version 2 update 2).

<http://h71028.www7.hp.com/enterprise/cache/9931-0-0-225-121.aspx>

Event Monitoring Service, Online Diagnostics, and System Fault Management

In addition, you must install the OnlineDiag bundle with EMS A.04.00 or later and the System Fault Management provider package A.02.00.01.01 or later, available from

<https://payment.ecommerce.hp.com/portal/swdepot/displayProductInfo.do?productNumber=SYSFAULTMGMT>

Install these packages on the systems you want to manage

Validate that the system you want to manage has the EMS wrapper provider.

Log onto the target system after installation. The command `cimprovider -ls` is used to verify that the EMS wrapper is installed and running. The syntax is

```
usage: cimprovider -d -m module
        -e -m module
        -r -m module [ -p provider ]
        -l [ -s | -m module ]
```

The EMSWrapperProviderModule must be listed as below:

```
# cimprovider -l -s
MODULE                                STATUS
OperatingSystemModule                 OK
ComputerSystemModule                 OK
ProcessModule                         OK
IPProviderModule                     OK
DNSProviderModule                   OK
NTPProviderModule                   OK
NISProviderModule                   OK
SDProviderModule                     OK
IOTreeModule                         OK
HP_NParProviderModule                OK
HPUXLANProviderModule               OK
HP_iCODProviderModule               OK
cpuprovidermodule                   OK
HPUX_ControlProviderModule          OK
EMSWrapperProviderModule             OK
ErrorIndicationConsumerModule       OK
MemoryModule                         OK
HPUXLVMProviderModule               OK
```

If it is not listed, then it is not installed correctly or not running. Refer to the System Fault Management documentation for installation instructions.

http://docs.hp.com/en/diag/sfm/sfm_inst.htm

Adding systems with WBEM to HP SIM through the command line interface

Sign into the HP SIM system. Note that the HP SIM server can be running on HP-UX, Windows, or Linux. The examples below are from HP SIM running on an HP-UX system. However, the commands are the same. Run the commands from:

On HP-UX:

```
/opt/mx/bin
```

You might want to set the path to simplify your typing (`set path=$PATH:/opt/mx/bin`)

On Linux:

```
/opt/mx/bin
```

On Windows:

```
C:\Program Files\HP\System Insight Manager\bin
```

This path is set by the HP SIM installation on Windows. Enter the commands from a command window.

1. Add the necessary root/password pair to HP SIM through `mxnodesecurity` so that HP SIM can correctly identify the managed systems.

The syntax for `mxnodesecurity` is given below and this command must be ran with the root privilege.

```
Usage:
mxnodesecurity -a -p protocol -c username:password [-n
systemname]
mxnodesecurity -a -f filespec
mxnodesecurity -r -p protocol [-n systemname]
mxnodesecurity -r -f filespec
mxnodesecurity -l [-p protocol] [-n systemname]
```

where *protocol* is one of `snmp`, `wbem`, or `dmi`.

For example:

```
$ mxnodesecurity -a -p wbem -c root:provider -n managedsystem
```

2. (Optional) Validate that the system protocol access setting has been accepted

For example:

```
$ mxnodesecurity -l -n cupux17
TARGET NODE PROTOCOL NAME PASSWORD
cupux17      wbem      root      *****
```

3. Use `mxnode` to add the node(s) from which you wish to receive indications:

The syntax for `mxnode` is:

```
Usage:  mxnode -a nodes [-w]
        mxnode -a -f filename [-w]
        mxnode -a -m -f filename [-w]
        mxnode -m [-p] -f filename [-w]
        mxnode -r nodes
        mxnode -r -f filename
        mxnode -ln [nodes]
        mxnode -ld [nodes]
        mxnode -lt [nodes]
        mxnode -lf [nodes] [-b encoding]
        mxnode -lmpo
nodes = [nodename|hostname|ipaddress]...
a      = add node
m      = modify node (only option that allows add/modify/remove
        of MPOs through XML)
r      = remove node
f      = file (followed by file pathname)
l      = list
ln     = list nodes by name
ld     = list details of a node
lt     = list all node data in tabular format
lmpo   = list all nodes with associated MPOs
p      = prune (forces removal of any omitted MPOs in XML)
b      = specify encoding of input XML
w      = wait for add/modify/remove operation to complete
```

NOTE: You must have full-configuration-rights on the CMS to add systems.

HP recommends using the `-w` option so you know when the operation has completed since it can take up to a minute depending on response time from the managed system.

```
$ mxnode -a managednode -w
Waiting for node(s) to be added...
$
```

4. (Optional): Validate that the system has been added correctly.

Use `mxnode` to list the details of the managed system:

```
$ /opt/mx/bin/mxnode -ld managednode
```

Output should look similar to this one:

```
$ mxnode -ld 172.24.30.143
System name: 172.24.30.143
Host name:
IP addresses: 172.24.30.143
OS name: HPUX
OS revision: 11.11
OS revision text: HP-UX B.11.11 U
OS vendor: HP
Protocols: WBEM:1.0 SNMP:1.0 SSH:SSH-2.0-OpenSSH_3.5p1
GUID: 00000000864162de0000000300000035
Device type: Server
Device subtype: HP9000
Model: 9000/800/A500-7X
Added by: mxadmin
Added on: Jul 28, 2005 11:39:45 AM
Modified by: mxadmin
Modified on: Jul 29, 2005 12:01:40 PM
Monitoring: Not suspended
OS description: HP-UX
Preferred node name: 172.24.30.143
System description: HP-UX parisc3 B.11.11 U 9000/800 809980646
Location:
System name locked: No
System attributes locked: No
discovery.source: cli
```

5. Subscribe for indications

The syntax for `mxwbemsub` is :

```
Usage:
mxwbemsub -a [destination] ( (-n <nodenames> ) | (-f <filespec> ) )
mxwbemsub -r [destination] ( (-n <nodenames> ) | (-f <filespec> ) )
mxwbemsub -l [destination] ( (-n <nodenames> ) | (-f <filespec> ) )
mxwbemsub -m [current destination] <new destination> ( (-n
<nodenames> ) |
(-f <filespec> ) )
```

For example:

```
$ mxwbemsub -a -n managednode
Create Subscriptions for:
managednode
Host URL to connect to is = https://managednode:5989/cimom
Indication subscription successfully created.
```

Adding systems with WBEM to HP SIM through the GUI

The process is the same for any HP SIM installation, using either Internet Explorer or Mozilla to connect to HP SIM.

Sign into HP SIM through your browser. You must have rights to add systems.

1. Add the WBEM credentials to the global protocol settings. Select **Options**→**Security**→**Global Protocol Settings**, and add the root/password credentials under the **WBEM settings** section.
2. Discover the systems. Select **Options**→**Discovery**, and select **Manual Discovery**. Add the system name (fully qualified DNS name is best).

(Optional) Verify that HP SIM has correctly discovered the system.

The simple way to do this is to type the name of the system into the **Search** panel and click **Search**. When the search completes, select the system and then select **Properties** from the menu (select **Tools**→**System Information**→**Properties**), and then click **Run Now**.

The resulting page includes data that is *only* retrieved through WBEM.

3. Subscribe for WBEM events.

From the All Systems collection, select the systems that you want to retrieve indications from by selecting the checkbox to the left of the each system. Select **Options**→**Events**→**Subscribe to WBEM events**, and then click **Run Now**. The task starts and should complete with no errors.

Sending a test indication

You can validate everything is set up correctly by generating a test event on the managed system.

Execute the following command on the managed system:

```
# /opt/resmon/sbin/send_test_event disk_em
```

To verify that HP SIM has received the event, you must now access the HP SIM GUI.

Viewing the WBEM indications

Sign into HP SIM through a browser.

Select **All Events** in the **Systems and Events** panel.

There is an informational event under **Events**→**Event Type**, called **HP-UX EMS Disk Event**. Click the event type to see the details.

For more information

- **HP Systems Insight Manager**
www.hp.com/go/hpsim
- **IETF secsh working group home page**
www.ietf.org/html.charters/secsh-charter.html
- **OpenSSH**
www.openssh.org

© 2004, 2007 Hewlett-Packard Development Company, L.P. The information contained herein is subject to change without notice. The only warranties for HP products and services are set forth in the express warranty statements accompanying such products and services. Nothing herein should be construed as constituting an additional warranty. HP shall not be liable for technical or editorial errors or omissions contained herein.

Java is a U.S. trademark of Sun Microsystems, Inc. Linux is a U.S. registered trademark of Linus Torvalds. Windows is a U.S. registered trademark of Microsoft Corporation.

446752-001, 01/2007